

sales@carolinatarps.com 1-855-481-1457

PIONEER E300

PIONEER E300 INSTALLATION GUIDE

DOO

Landscape Installation



- 1) Find the two end plates. The bearing and crank handle will be assembled on the driver side end plate (with the cut out), *see D above*. On both ends the 3-piece bearing should be inserted on the inside of the end plate, *see figure 1a*, with the set screws facing the roller tube. Do not insert the bearing from the outside of the end plate, *see figure 1b*.
- 2) Insert a bearing and the stub shaft into the passenger side end plate.
- 3) Place the 3-piece roller tube between the two end plates, and insert the stub shaft through the bearing and into the roller tube. Tighten the set screw on the bearing. At the driver side end insert the crank handle though the bearing and into the roller tube. Tighten the set screw on the bearing.
- 4) Select your mounting location and adjust the axle to the length needed. Mount the two end plates on the sides of the trailer with the 5/16" self tapping bolts.
- 5) Using the tek screws, mount the tarp on the roller tube, starting in the middle of the roller tube and working outwards. At the two telescoping sections of the roller tube, make sure to insert a screw in order to set the roller tube length.
- 6) If you have a pull bar, then slide in into the pocket at the other end of the tarp. On one side of the bar place the tarp guide. It may be necessary to cut the other end of the bar to fit the width of the trailer. Cut the pull bar with 1" to spare each side. Then cut the PVC pipe to fit between the tarp and the end cap to keep the tarp from sliding.
- 7) Secure the rope through the grommets in the center of the tarp around the pull bar.



Congratulations on your new Pioneer E300 Landscaping Tarp System from Carolina Tarps! If you have any trouble installing or need to order replacement parts, please visit www.carolinatarps.com or call 1-855-481-1457